

Installing Windows NT 4.0 drivers on the AJP 7200

PREPARATION: What do you need for the installation?

You will need the driver CD ROM supplied with your notebook, and your copy of Windows NT 4 for this procedure.

Installing the display drivers.

Right click on any empty part of the desktop, a small pop-up menu will appear. Click on **Properties**, Select the **Settings** tab, Click on **Display Type** (this is at the bottom right of the screen). A new dialogue window will appear called **Display Type** the adapter type will be identified as **VGA compatible display adapter**, which is incorrect. Click on the **Change**, then click on the **Have disk** and when prompted with **Copy manufacturer's files from:** type **d:\video\nt40. Chips Video accelerated (64300/10 65535/40/45/48/50/54/55)** will be highlighted click on **OK**. You will then be prompted if you want to **install a third party driver** click on **Yes**. Windows NT will then copy some files. Once the files are copied the message **The drivers were successfully installed** will appear click on **OK**. Click on **Close** and this will take you back to the **Display Properties window**. Click on **Close** and you will be prompted to re-start your computer, click on **Yes**.

Once the machine has re-started Windows NT will report that a new graphics driver has been installed, click on **OK**. The **Display Properties Windows** will be shown. Click on the **Color Palette** and the choose **16777216 Colors** and under **Desktop Area** move the slider bar over to **1024 by 768 pixels**. Now click on **Test** and then **OK** a test screen will appear, once the windows NT desktop area re-appears you will be asked if you saw the bitmap clearly, click **OK**.

Note: If you find that the screen font is too small, go to **Display Properties, Settings** and under **Font size** select **Large Fonts**, click on **Apply**.

The display driver installation is now complete click on **OK** to exit from the **Display Properties** window.

Installing your Sound Drivers.

Click on your **Start** button and select **Settings**. A pop-up menu will appear. Click on **Control panel** here. In control panel open the **Multimedia** icon. Click on the **Devices** Tab and highlight **Audio Devices** by clicking once on it. Now click on **Add...** A new window will appear with **Unlisted or Updated Driver** highlighted click on **OK**. The system will then prompt you with the following message **Insert the disk with the unlisted, updated or vendor-provided driver in:** type **d:\audio\nt40** and then click on **OK**. A new window will appear with **ES1878 Audio Drive 2.00.40** highlighted click **OK**. A new window will now appear click on **Re-start Your Computer**.

The sound driver installation is now complete.

PCMCIA

If you find that PCMCIA cards are causing your machine to hang on shut down we recommend installing Service Pack 3 or installing the Microsoft PCMCIA fix which can be obtained from the following URL

<ftp://ftp.microsoft.com/bussys/winnt/winnt-public/fixes/usa/nt40/hotfixes-postSP1/pcmcia-fix>

Notes are also available for the D-Link 660 and the Apex Clipper Com Modem under Windows NT 4.0 and can be provided on request.

We hope the above information is sufficient to enable you to setup your 7200. Meanwhile if you have any problems do not hesitate to contact our Technical Support Department.

Telephone	0208 -208 - 9799
Fax	0208 -208 - 9717
Email	support@ajp.co.uk
Web	www.ajp.co.uk

Telephone Technical Support Hours, Mon - Fri	9:00 - 1:00, 2:00 - 5:30
-------------------------------------------------	--------------------------