

Installing Windows NT 4.0 drivers of the AJP 8500M Series machine.

DISCLAIMER: This installation guide assumes that the user has competent knowledge of Windows NT 4.0

PREPARATION: What do you need for the installation?

You will need the driver CD-ROM supplied with your notebook, and your copy of Windows NT 4 for this procedure.

Installing the Display Drivers.

Right click any part of the desktop, a small pop-up menu will appear. Click on **Properties**. Select the **Settings** tab. Click on **Display Type** (this is at the bottom right of screen). A new dialogue window appears called **Display Type**. The adapter type will be identified as **VGA compatible display adapter**, which is incorrect. Click on the **Change** button, then click on the **Have Disk** button. When prompted with **Copy manufacturer's files from:** type **d:\video\nt40. S3 Incorporated Display Driver v3.27.08generic Engineering Release** will be highlighted click on **OK**. You will then be prompted if you want to **install a third party driver** click **Yes**. Windows NT will then copy some files. Once the files are copied the message **The drivers were successfully installed** will appear click **OK**. Click on **Close** and this will take you back to the **Display Properties window**. Click on **Close** and you will be prompted to restart your computer. Click on **Yes**.

Once the machine has re-started, Windows NT will report that a new graphics driver has been installed. Click on **Ok**. The **Display Properties window** will be shown. Click on the **Colour Palette** and choose **16777216 Colours** and under **Desktop Area** move the slider bar over to **1024 by 768 pixels**. Now click on **Test** and then **Ok**. A test screen will appear. Once the Windows NT desktop area re-appears you will be asked if you saw the bitmap clearly. Click **Ok**.

Note: If you find that the screen font is too small, go to **Display Properties, Settings** and under **Font Size** select **Large Fonts**, click **Apply**.

The display driver installation is now complete. Click **Ok** to exit from the **Display Properties** window.

Installing your Sound Drivers.

Click on your **Start** button and select **Settings**. A pop-up menu will appear. Click on **Control panel** here. In control panel open the **Multimedia** icon. Click on the **Devices** tab and highlight **Audio Devices** by clicking once on it. Now click on **Add...** A new window will appear with **Unlisted or Updated Driver** highlighted. Click on **Ok**. The system will then prompt you with the following message **Insert the disk with the unlisted, updated or vendor provided driver in:** type **d:\audio\nt40** and then click **Ok**. **ES1879/1869/1878/1868/1887/1888 AudioDriver 2.00.74** should be highlighted. Click **Ok**. Another window will be shown saying that the sound drivers have been installed. Click on **Restart Now**.

The sound driver installation is now complete.

We hope the above information is sufficient to enable you to set up your 8500M. Meanwhile if you have any problems do not hesitate to contact our Technical Support Department.

Telephone	0208 - 208 – 9799
Fax	0208 - 208 – 9717
Email	support@AJP.co.uk
Web	www.AJP.co.uk
Mon. – Fri.	9:00 - 5:30
Sat	9:00 – 2:00